



C&W Specialist Salt

Sodium Chloride for Corrosion Testing

- ✓ Analytical Certificate guarantees consistent quality
- ✓ Meets ISO 9227 and ASTM B117
- ✓ Moisture and dirt-resistant packaging
- ✓ Easily soluble
- ✓ Available in handy 5 kg buckets and economic 25 kg
- ✓ Clean, low-dust processing
- ✓ Special grain size prevents lumps and excess dust

Any Questions? @ sales.service@cw-spec.com ☎ +44 (0) 2039 3635 65

C&W Specialist Salt is Sodium Chloride which quality complies to the stringent ASTM B117 standard. The Sodium Chloride's grain and purity is specially formulated for saline spray (fog) for corrosion testing with C&W Salt Spray and CCT cabinets. Obviously C&W Specialist Salt also creates the ideal saline spray for cabinets from other brands.



Conveniently Packed

The salt is conveniently and safely packed in 25 kg or 5 kg containers keeping the salt free from moisture and contamination. One 5 kg bucket dissolved in 100 litres of water creates the perfect mixture for salt spray testing. No weighing needed. Both the handy 5 kg buckets and the economic 25 kg buckets are fitted with a handle for optimal lifting.

C&W Specialist Salt is the ideal companion for C&W cabinets. Salt contracts will be available providing benefits in the procurement of cabinets and service.

www.cw-spec.com